

MCF88 DATA FRAME FORMAT

Revision History:

Author	Release	Note
S.Colognato	1.0 29/09/2016	First release
P. Bagnara	1.1 30/09/2016	
P. Bagnara	1.2 05/06/2017	- added option type in time sync and
		removed threshold option
		 added off message
		 added set period message
		 added report data message
		 power message modified
P. Bagnara	1.3 31/08/2017	 added generic sensor
		 added battery percentage to tprh and
		kamstrup messages
P. Bagnara	1.4 27/10/2017	 Added encryption
P. Bagnara	1.5 11/01/2018	– Added lux/voc
P. Bagnara	1.6 06/02/2018	 Added pressure compensation
P. Bagnara	1.7 21/03/2018	 Added analog input, ultrasuoni, modbus,
		davis
P. Bagnara	1.8 22/03/2018	 Minor updates
P. Bagnara	1.9 11/04/2018	 Minor updates
P. Bagnara	1.10 01/06/2018	 Minor updates
P. Bagnara	1.11 18/06/2018	– CO2
P. Bagnara	1.12 26/07/2018	– PM2
P. Bagnara	1.13 02/08/2018	 Device code list
P. Bagnara	1.14 07/09/2018	 Added Davis data description
P. Bagnara	1.15 23/10/2018	 Fixed CO2 uplink id
P. Bagnara	1.16 16/11/2018	– Links added
P. Bagnara	1.17 29/11/2018	– Minor updates

The document describes encryptions related to LoRaWAN™ payloads. Relevant chapters per product of interest are marked with a cross "X".



	1. UPLINK MESSAGES from END-DEVICES						<u>DWNL</u> to ENI			<u>GES</u>						
PRODUCT PART NUMBER	1.1 TIME SYNC REQUEST	1.2 TEMPERATURE/PRESSURE/HUMIDITY	<u>1.3 UART</u>	1.4 POWER	<u>1.5 IO</u>	<u>1.6 REPORT DATA</u>	1.7 TEMPERATURE/PRESSURE/HUMIDITY/LUX/VOC	1.8 ANALOG DATA	1.9 T/P/RH/LUX/VOC/CO2	2.1 TIME SYNC ANSWER	<u>2.2 UART</u>	2.3 IO MESSAGE	2.4 SET PERIOD	2.5 METERING REQUEST	2.6 SET PRESSURE COMPENSATION	2.7 OFF COMMAND
MCF-LW06485	Х					Х				Х			Х			Х
MCF-LW06VMC	Х									Х			Х			Х
MCF-LW06232	Х		Х							Х	Х		Х			Х
MCF-LW06420	Х							Х		Х			Х			Х
MCF-LW06010	Х							Х		Х			Х			Х
MCF-LW06424	Х							Х		Х			Х			Х
MCF-LW06420D	Х							Х		Х			Х			Х
MCF-LW06010D	Х							Х		Х			Х			Х
MCF-LW06424D	Х							Х		Х			Х			Х
MCF-LW06KIO	Х				Х					Х		Х				Х
MCF-LW12PLG	Х			Х	Х					Х		Х	Х	Х		Х
MCF-LW12MET	Х			Х	Х					Х		Х	Х	Х		Х
MCF-LW13IO	Х				Х					Х		Х				Х
MCF-LW13MIO	Х				Х					Х		Х				Х
MCF-LW12TERWP	Х	Х								Х			Х		Х	Х
MCF-LW12TER	Х	Х								Х			Х		Х	Х
MCF-LW12VOC	Х						Х			Х			Х		Х	Х
MCF-LW12CO2	Х								Х	Х			Х		Х	Х
MCF-LWWS00	Х					Х				Х			Х			Х
MCF-LWWS01	Х					Х				Х			Х			Х
MCF-LW06DAVK	Х					Х				Х			Х			Х
MCF-LW06DAVKP	Х					Х				Х			Х			Х



HOME

HOME

1. UPLINK MESSAGES FROM END-DEVICES

1.1 TIME SYNC REQUEST

name	size [byte]	hex value	mean
Uplink ID	1 byte	01	Time sync request
Sync ID	4 byte	XX XX XX XX	ID of sync request
Sync Version	3 byte (optional)	XX XX XX	Major and minor version and build
		02 00	for MCF-LW06VMC
		02 01	for MCF-LW06232
		02 02	for MCF-LW06KAM
		02 03	for MCF-LW06485
		02 04	for MCF-LWWS00 and MCF-LW06DAVK
		02 05	for MCF-LW06KIO
		02 06	for MCF-LW12WAM
		02 07	for MCF-LW06420/010 OBSOLETE
		02 08	for MCF-LWWS01 and MCF-LW06DAVKP
		02 09	for MCF-LW06420
		02 0A	for MCF-LW06010
Application two		02 0B	for MCF-LW06424
Application type	2 byte	02 0C	for MCF-LW06420D
		02 0D	for MCF-LW06010D
		02 0E	for MCF-LW06424D
		04 00	for MCF-LW12TER
		04 01	for MCF-LW12TERWP
		04 02	for MCF-LW12VOC
		04 03	for MCF-LW12CO2
		04 05	for MCF-LW12PM00
		07 00	for MCF-LW12MET
		07 01	for MCF-LW13IO
		07 02	for MCF-LW12PLG
		09 00	for MCF-LW13MIO
RFU	X byte	XX	Optional RFU byte

The device, after sending the message, waits for the time sync answer (<u>2.1 TIME SYNC ANSWER</u>). If nothing received, it will try to send the request a couple of times. If error persists, it will try again after a few hours.

If it receives the right answer, it aligns the internal clock and a new sync message will be sent after a week to overcome real time clock drift.



1.2 TEMPERATURE/PRESSURE/HUMIDITY

HOME

name	size [byte]	hex value	mean
Uplink ID	1 byte	04	Temperature/Pressure/Humidity
	10 byte	XX XX	Measure 1, refer to Note1
Data	10 byte	XX XX	Measure 2, refer to Note1
	10 byte	XX XX	Measure 3, refer to Note1
Batt %	1 byte (optional)	XX	Battery percentage
RFU	4 byte (optional)	XX XX XX XX	Optional RFU byte

Note1:

The 10 bytes for each measurement are divided as follows:

- 4 bytes are for the date and time. The MSB (most significant byte) is on the right so they must be read from the right. The 4 byte in reverse order are as follows:
 - 7 bit for the offset of the year, starting from the year 2000
 - 4 bit per month
 - 5 bit for day of the month
 - 5 bits for hour
 - 6 bits for minutes
 - 5 bits for half the seconds. The seconds range is from 0 to 31, so the result should be multiplied by 2 to find the actual seconds of the measurement.
- 2 bytes for temperature. The temperature is represented by a signed integer with the least significant byte first. The temperature is expressed in hundreds of a °C degree.
- I byte for humidity. Relative humidity is an unsigned integer corresponding to twice the percentage of humidity.
- > 3 bytes for pressure. Pressure is an unsigned integer with the least significant byte first; it is expressed in Pascal.



Example

Sample payload:

04dc7e3721b40a47608801dd7e3721b10a43608801e07e3721b20a425d8801 Remove the first byte and divide the other 30 into 3 parts by 10 byte that correspond to 3 measurements. The 3 measurements will be: • dc7e3721b40a47608801

- dd7e3721b10a43608801
- e07e3721b20a425d8801

Decipher the first measurement dividing it by groups and applying the necessary transformations:

- Measurement date: dc 7e 37 21
 - Byte swapping, result: 21 37 7e dc
 - The result in bits will be: 00100001 00110111 01111110 11011100
 - The bits are divided as explained above
 - Year: 0010000
 - ♦ Result: 16
 - > 2000+16 = 2016
 - Month: 1001
 - Result: 9
 - Day: 10111
 - Result: 23
 - Hour: 01111
 - ♦ Result: 15
 - Minutes: 110110
 - Result: 54
 - Seconds: 11100
 - Result: 28
 - ▶ 28*2 = 56
 - The date of the measurament will be: 23/09/2016 15:54:56.
- o Temperature: b40a
 - Byte swapping, result: 0ab4
 - The result (with sign) will be +2740 with two decimal places, then + 27.40 °C.
- Humidity: 47

•

- In decimal is 71, the humidity is 71/2 = 35.5% rH.
- o Pressure: 608801
 - Byte swapping, result: 018860
 - In decimal, the result is 100448, with two decimal places the pressure is 1004.48 hPa.

1.3 UART

<u>HOME</u>

name	size [byte]	hex value	mean
Uplink ID	1 byte	05	uart
Data	Application related	XX XX	Data to be forwarded, message sent via serial or usb command.



1.4 POWER

HOME

The recurrent message of metering end-nodes is as follows:

name	size [byte]	hex value	mean
Uplink ID	1 byte	09	Power
Date/Time	4 byte	XX XX XX XX	Date and time (as for Note1)
Active energy	4 byte (s32 LSB)	XX XX XX XX	Cumulative active energy (Wh)
Reactive energy	4 byte (s32 LSB)	XX XX XX XX	Cumulative reactive energy (VARh)
Apparent energy	4 byte (s32 LSB)	XX XX XX XX	Cumulative apparent energy (VAh)
Running Time	4 byte (u32 LSB)	XX XX XX XX	Seconds of running (s)

After a message of metering request (2.5 METERING REQUEST) the uplink is as follows:

name	size [byte]	hex value	mean
Uplink ID	1 byte	09	Power
Date/Time	4 byte	XX XX XX XX	Date and time (as for <u>Note1</u>)
Active energy	4 byte (s32 LSB)	XX XX XX XX	Cumulative active energy (Wh)
Reactive energy	4 byte (s32 LSB)	XX XX XX XX	Cumulative reactive energy (VARh)
Apparent energy	4 byte (s32 LSB)	XX XX XX XX	Cumulative apparent energy (VAh)
Active power	2 byte (s16 LSB)	XX XX	Active power (W)
Reactive power	2 byte (s16 LSB)	XX XX	Reactive power (VAR)
Apparent power	2 byte (s16 LSB)	XX XX	Apparent power (VA)
Voltage	2 byte (u16 LSB)	XX XX	Voltage (dV RMS)
Current	2 byte (u16 LSB)	XX XX	Current (mA RMS)
Period	2 byte (u16 LSB)	XX XX	Period (us)
Running Time	4 byte (u32 LSB)	XX XX XX XX	Seconds of running (s)

1.5 IO

name	size [byte]	hex value	mean
Uplink ID	1 byte	0A	Input/output
Date/Time	4 byte	XX XX XX XX	Date and time (as for <u>Note1</u>)
Inputs	4 byte (u32 LSB)	XX XX XX XX	Bit mask of the inputs
Outputs	4 byte (u32 LSB)	XX XX XX XX	Bit mask of the outputs
Events	4 byte (u32 LSB)	XX XX XX XX	Bit mask of input events



This uplink format is for 32 inputs and 32 outputs. Relevant bits depend on the device part number and its I/O capability.

In case of MCF-LW12PLG, the input status represents the status of the mains (1 for mains present, 0 for mains not present).

1.6 REPORT DATA

<u>HOME</u>

name	size [byte]	hex value	mean
Uplink ID	1 byte	0B	Report data
Report ID		ΟΥ	for MCF-LW06KAM, "Y" is the sequential number of the transmission in progress, is incremented at the end of each transmission.
	1 byte	1Y	for MCF-LW06485, "Y" is the sequential number of the transmission in progress, is incremented at the end of each transmission.
		2Y	for MCF-LWWS00, MCF-LWWS01, MCF-LW06DAVK and MCF- LW06DAVKP, "Y" is the sequential number of the transmission in progress, is incremented at the end of each transmission.
Frame ID	1 byte	xx	Progressive frame index, increased at each transmission with the same identifier
Data	132 byte	xx xx	for MCF-LW06485 refer to <u>Note2</u> for MCF-LWWS00 refer to <u>Note3</u> for MCF-LW06DAVK refer to <u>Note3</u> for MCF-LWWS01 refer to <u>Note4</u> for MCF-LW06DAVKP refer to <u>Note4</u>

Note2:

The modbus frame consists of at least 3 bytes.

In case of error, it will return 0200XX where XX indicates the type of error.

In case of success, the first two bytes (us16 LSB) indicate the length (including the two bytes) and the remaining bytes is the data read from the peripheral Modbus device(s).

Note3:

The Davis weather station frame is made up of at least 4 bytes.



In the event of an error it returns XXYYZZZZ, where XX indicates the data version, YY the type of error, ZZZZ the size of the read data.

If case of successful reading of weather data, the data sequence will be as in the following table, data with more than 1 bytes is LSB:

name	size [byte]	mean
Data version	1 byte	Current version is 0
Davis type	1 byte	16 (0x10) for Vantage Pro/Pro2
Barometer data	2 byte (u16 LSB)	Unit is mHg (Hg/1000)
Outside temperature	2 byte	Unit is d°F (°F/10)
Wind speed	1 byte	Unit is mph (miles per hour)
Avg wind speed	1 byte	Unit is mph
Wind direction	2 byte	Value from 1 to 360 degrees. (0° is no wind data, 90° is East, 180° is South, 270° is West and 360° is north)
Outside humidity	1 byte	Relative humidity in %
Rain rate	2 byte	Number of rain clicks (0.2mm or 0.01in). inches/hour
UV	1 byte	Unit is in UV index
Solar radiation	2 byte	The unit is in watt/meter2
Day rain	2 byte	Number of rain clicks (0.2mm or 0.01in)
Day et	2 byte	Unit is inch / 1000
Soil moisture	4 byte	Unit is in centibar. It supports four soil sensors.
Leaf wetness	4 byte	Number from 0 to 15 with 0 meaning very dry and 15 meaning very wet. It supports four leaf sensors.
Forecast icons	1 byte	Single Bit meaning is: 0x01 = Rain 0x02 = Cloud 0x04 = Partly cloudly 0x08 = Sun 0x10 = Snow Mixed forecasts are possible. See examples below.
Bar trend	1 byte	Signed byte that indicates the current 3-hour barometer trend. It is one of these values: -60 = Falling Rapidly = 196 (as an unsigned byte) -20 = Falling Slowly = 236 (as an unsigned byte) 0 = Steady 20 = Rising Slowly 60 = Rising Rapidly 80 = ASCII "P" = no trend info is available Any other value means that the Vantage does not have the 3 hours of bar data needed to determine the bar trend.
RFU	3 byte	Optional RFU bytes. Only present in MCF- LWWS01 and MCF-LW06DAVKP



Examples of Forecast icons:

decimal	hex	Segments shown	Forecast
8	0x08	Sun	Mostly Clear
6	0x06	Partial Sun + Cloud	Partly Cloudy
2	0x02	Cloud	Mostly Cloudy
3	0x03	Cloud + Rain	Mostly Cloudy, Rain within 12 hours
18	0x12	Cloud + Snow	Mostly Cloudy, Snow within 12 hours
19	0x13	Cloud + Rain + Snow	Mostly Cloudy, Rain or Snow within 12 hours
7	0x07	Partial Sun + Cloud + Rain	Partly Cloudy, Rain within 12 hours
22	0x16	Partial Sun + Cloud + Snow	Partly Cloudy, Snow within 12 hours
23	0x17	Partial Sun + Cloud + Rain + Snow	Partly Cloudy, Rain or Snow within 12 hours

Note4:

Refer first to <u>Note3</u>. In addition are PM readings are on a separate uplink. The field "Data", in case of success, is as follow:

- ➢ 4 bytes are for the date and time (as per <u>Note1</u>)
- > 6 bytes are for PM measures: 2 bytes for each measurement, formatted as LSB, reporting in order pm1.0, pm2.5 and pm10 in μg/m3

1.7 TEMPERATURE/PRESSURE/HUMIDITY/LUX/VOC HOME

name	size [byte]	hex value	mean
Uplink ID	1 byte	0C	Temperature/Pressure/Humidity/Lux/Voc
Data	14 byte	XX XX	Measure 1, refer to Note5
Data	14 byte	XX XX	Measure 2, refer to Note5
Batt %	1 byte (optional)	XX	Battery percentage
RFU	6 byte (optional)	XX XX XX XX	Optional RFU byte

Note5:

The first 10 bytes for each measurement are the same as defined in <u>Note1</u>, the following 4 bytes are as follows:

- 2 bytes for illuminance. Luminance is represented by an unsigned integer with the least significant byte first. The Luminance is reported in lux (lx).
- 2 bytes for VOC (Volatile organic compounds). The VOC level is reported according to setup of the device made with LoRaTool APP, as unsigned with the least significant byte first:
 - o index (IAQ indoor air quality) between 0 (clean air) and 500 (heavily polluted air)
 - o bVOC value between 500ppb (clean air) and 50000ppb (heavily polluted air)



1.8 ANALOG DATA

HOME

name	size [byte]	hex value	mean
Uplink ID	1 byte	0D	Analog data
	1 byte	00	for MCF-LW12WAM
Turne		01	for MCF-LW06420 and MCF-LW06420D
Туре		01	for MCF-LW06010 and MCF-LW06010D
		01	for MCF-LW06424 and MCF-LW06424D
Data	134 byte	XX XX XX	Refer to <u>Note6</u>

Note6:

Data are as follow:

- ➤ 4 bytes are for the date and time (as per <u>Note1</u>)
- > 8 byte for measurements, 2 byte for each measurement, formatted as LSB with the following meaning:
 - Bit 0..11: measured value, to be rescaled according to the type
 - Bit 12: equal to 1 if error: if the measured value is 0 means sensor disconnected (4-20mA only); greater or equal to 0xF00 it is a generic measurement error
 - Bit 13..14: measure type:
 - 0: 4-20 mA
 - 1: 0-10 V
 - 2: 0-5 V
 - Bit 15: RFU



1.9 T/P/RH/LUX/VOC/CO2

<u>HOME</u>

name	size [byte]	hex value	mean		
Uplink ID	1 byte	0E	T/P/rH/Voc/Lux/Co2		
Data	16 byte	XX XX	Measure 1, refer to Note7		
	16 byte	XX XX	Measure 2, refer to Note7		
Batt %	1 byte (optional)	XX	Battery percentage		
RFU	2 byte (optional)	XX XX	Optional RFU byte		

Note7

Data are as follow:

- > The first 14 bytes for each measurement are the same as defined in <u>Note5</u>
- Following 2 bytes are for CO2. CO2 concentration is represented by an signed integer with the least significant byte first. The CO2 is expressed in ppm.



2. UPLINK MESSAGES FROM END-DEVICES

2.1 TIME SYNC ANSWER

<u>HOME</u>

HOME

name	size [byte]	hex value	mean
Downlink ID	1 byte	00	Time sync answer
Sync ID	4 byte	XX XX XX XX	Copy of received Sync ID
Date/time	4 byte	XX XX XX XX	Date/time GMT, refer to Note8

Note8:

Date/time GMT in DOS format with epoch 2000. Sent as LSB. In bits, will be:

- 7 bits for year, starting from the year 2000
- ➢ 4 bits for year
- > 5 bits for day in the month
- > 5 bits for hour
- ➢ 6 bits for minutes
- ➢ 5 bits for half of seconds

Example

For date 23/09/2016 15:54:56:

- Year 2016 = bit 0010000
- Month 9 = bit 1001
- Day 23 = bit 10111
- Hour 15 = bit 01111
- Minutes 54 = bit 110110
- Seconds 56 (/ 2 = 28) = bit 11100

The sequence in bits is "001000010011011101111101101100", corresponding to the hexadecimal "21377edc", which will be sent as LSB: dc 7e 37 21



2.2 UART

HOME

name	size [byte]	hex value	mean
Downlink ID	1 byte	03	Uart
Data	Application related	xx xx	Data to be forwarded, proprietary protocol.

2.3 IO MESSAGE

<u>HOME</u>

name	size [byte]	hex value	mean		
Downlink ID	1 byte	04	General message		
Option	1 byte	00	Identify an IO message		
Enable	4 byte (u32 LSB)	XX XX XX XX	Bit mask of the outputs to be enabled		
Disable	4 byte (u32 LSB)	XX XX XX XX	Bit mask of the outputs to be disabled		

If both the enable and the disable bit are equal to zero, the current status will be sent

2.4 SET PERIOD

HOME

name	size [byte]	hex value	mean		
Downlink ID	1 byte	04	General message		
Option	1 byte	01	Identify a SET PERIOD message		
Option 2	1 byte	xx	Set device operation period in minutes (note that some devices have a minimum period, eg MCF-LW12TER 10 min, MCF-LW12VOC 15 min)		

2.5 METERING REQUEST

name	size [byte]	hex value	mean
Downlink ID	1 byte	04	General message
Option	1 byte	02	Identify a METERING REQUEST message. Requires special message metering
Option 2	1 byte	00	



2.6 SET PRESSURE COMPENSATION

name	size	[byte]	hex valu	e				mean	
Downlink ID	1 byte		04		General message				
Option	1 byte		03		Identify a SET PRESSURE				
	T Dyte	03			COMPENSATION message				
			xx xx					to the pres	
Offset	2 byte							sign) to com	
		motoro	Pa				nnude, see Pa	following tab	ne
		<i>meters</i> -305	-3700	<i>me</i> 16			18300		
		-305	-3000	17		_	18900		
		-244	-2200	17		_	19500		
		-122	-1500	18		_	20100		
		-61	-700	18			20700		
			100	19			21300		
		0	0			_			
				20		_	21900		
		61	700	20		-	22500		
		122	1500	21		_	23100		
		183	2200	21		_	23700		
		244	2900	22		_	24300		
		305	3600	23		_	24900		
		366	4300	23		-	25500		
		427	5000	24		_	26100		
		488	5700	24		_	26600		
		549	6400	25		_	27200		
		610	7100	26		_	27800		
		671	7800	26		_	28300		
		732	8500	27		_	28900		
		792	9200	28		_	29500		
		853 914	9800 10500	28 29		_	30000 30600		
		975	11200	29		_	31100		
		1036	11200	30		_	31600		
		1038	12500	29		_	30600		
		1158	13200	29		_	31100		
		1219	13800		07)48	-	31600		
		1219	14500	50	740	,	01000		
		1341	15100						
		1402	15700						
		1463	16400						
		1524	17000						
		1585	17600						



2.7 OFF COMMAND

name	size [byte]	hex value	mean
Downlink ID	1 byte	04	General message
Option	1 byte	FF	Identify an OFF message
Option 2	1	00	If it is a battery-powered device, turn off the module, otherwise it will restart it.